

CIDA GmbH – Schottener Weg 5 – 64289 Darmstadt

Einstellbogen „securPharm“ Honeywell Voyager 1400 G



1. Einstellungen zurück setzen



DEFOVR.

Remove Custom Defaults

2. Werkseinstellungen aktivieren



DEFAULT.

Activate Defaults

3. Werkseinstellungen setzen



MNUCDP.

Set Custom Defaults

4. Keyboard Germany



KBDCTY4.

Germany

5. Enter (CR)



VSUFCR.

**Add CR Suffix
All Symbologies**

6. Ton (beim einscannen)



BEPFQ12400.

*** Medium (2400 Hz)**

7. permanent an



PAPPST.

Presentation Mode

8. Idle Illumination
Presentation Mode



PWRIDL7.

Low

9. Sonderzeichen für Securpharm



KBDCAS3.

10. Änderungen übernehmen



MNUCDS.

Save Custom Defaults

11. Neue Einstellungen setzen



DEFAULT.

Activate Custom Defaults